

## 7 Adding a secondary administrator account

The first account created for the eflea watch is the main administrator account. You can add a secondary account to the app for two parents, for example, to be able to log in.

Adding a secondary administrator account requires authorization from the main administrator. A note appears when the secondary administrator account wants to add the same eflea watch, the main administrator will also receive the authorization notification.

**Note:** An app account can link multiple eflea watches; an eflea watch can also be connected to multiple secondary accounts with authorization from the main administrator. An invitation will appear in your app account (the main administrator) for authorization once the secondary administrator has scanned the same QR code of the watch in their app.

An invitation will appear in your app account (the main administrator) for authorization once the secondary administrator has scanned the same QR code of the watch in their app.

## 8 Precaution

Do not immerse the product in liquid or chemicals such as salt water and detergents.

Do not wear the product in the shower, as the different pH levels of shower gel, shampoo, and conditioner, or hot water, can damage the E flea watch.

Keep the product away from fire, heat, and other extremely high-temperature environments.

Keep the product out of reach of children.

Use only 5V chargers or USB ports, a higher voltage may damage the device.

Do not directly attach the magnetic charging cable to metal or conductive objects other than the eflea watch, as this may cause the charging connector to short circuit.

In case of excessive battery heating during charging, immediately disconnect it from the power supply.

Before first use, fully charge the battery.

If the watch heats up when you wear it, immediately remove it and turn it off through the watch settings or in the app.

Never connect to a mechanically damaged charger or if the batteries are swollen. Do not use batteries in this condition due to the risk of explosion.

When this product is in a discharged state and outside the service area, the location function does not work.

## 9 Delete an eflea watch from the app account

App My account Device list Select the device you want to delete Untie "Only untie yourself" or "Untie all contacts".

### Information

Postal code: H7S 2N3

Email: [info@efleawatch.com](mailto:info@efleawatch.com)

Postal address: 1804 Boulevard Le Corbusier, Suite #273 Laval, Quebec, Canada

# USER MANUAL

PLEASE READ THE INSTRUCTION MANUAL BELOW

Before first use, fully charge the battery.

**Note:** It is strictly forbidden to poke the microphone hole next to the SIM card tray with a needle.

## 1 How to use the watch

Turn on: press and hold the power button for 3 seconds to start the watch.

Turn off:

(Option 1) Click "Settings" / "Shutdown" / "OK" on the watch.

(Option 2) by the app: "Function" / "Remote Power Off"

Charge the battery: use the magnetic charging cable to attach to the back of the device (it will only connect one way).

Connect the other end of the cable to the supplied USB charger (5V 0.5A/5V 1A) or another power source. Do not use a fast charger, use only 5V chargers or USB ports, a higher voltage may damage the device.

**Note:**

(1) After turning on, the watch takes about a minute to read the SIM card information, the signal is normal and the timing is automatic.

(2) If the watch cannot be turned on normally, check if the watch has electricity. If it does not have electricity, charge it in time and turn it on again.

(3) If the card is not inserted or the card cannot be read after turning on, you can re-insert the card or replace the SIM card, and then restart to confirm the card reading.

## 2 Download and install the app

(Option 1) - Scan the following QR code, download and install the app.

(Option 2) - Scan the QR code to download the app on the E flea watch in "QR Code".

(Option 3) - Search "EWatch" in the App Store - Apple or Google Play

**Note:** During installation, the phone asks if you trust the app or if you allow access to the phone's location. Please select "Trust" and "Allow" each time.

## 3 Register the watch and connect

Open the app, new users will need to create a new account by clicking on the "Register" button at the bottom left, and complete the registration steps.

## 4 Connect the watch to your app account:

After successful registration, log in to your account, select "+" Add a watch, and scan the QR code of the watch.

**Note:** During the process, the phone asks if you trust the app or if you allow access to the phone's location. Please select "Trust" and "Allow" each time.



## 5 Product Features

- Real-time GPS, WIFI & CELL location
- Historical track, geofencing
- Calling (Contacts, SOS call button, two-way communication)
- Voice message
- Video chat
- Camera function
- Health pedometer
- Location update modes
- Clock
- Do Not Disturb
- Face Unlock
- Auto Answer
- Other settings and functions

## 6 Function Description

### Location update scheduling modes:

There are two location update modes. The user can combine the two modes for a better experience of location services.

(1). Manual positioning: Click "Refresh" in the real-time location map interface of the app or click "Function" "Real-time Position" to update the current location information. The watch will send the update as soon as possible.

(2). Real-time positioning: Updates the location data to the app based on the set interval when there is continuous movement.

**Note:** The user can click "Function" "Update Interval" to set the device's update interval in minutes. The value must be an integer between 1 and 86400. The default interval for real-time positioning mode is 10 minutes. In real-time positioning, the watch regularly updates the location on the app's map page and history.

### Reading the location history:

In the real-time location map interface of the app, click the "History" button on the right to check the location history playback.



### Geofencing (safe zone):

This feature defines a geofence (safe zone) perimeter and sends a push notification to the user if the tracker exits or enters the safe zone.

Click "Geofencing" Click the "+" icon in the upper right corner Click and drag the map to set the center point Drag to set the coordinate area range Click "v" at the top right Enter the fence name Click Confirm to save.

#### **Note:**

- (1) The app will display the entrance or exit alarm information of the geofence (Click "My account" "Message").
- (2) Once the watch has uploaded the location, the app can determine if it is entering or exiting the geofence.

## Calling:

### (1) Phone book:

Add a contact: Click "Function" in the app, select "Settings" → "Phone book" → Click the "+" icon → Insert the name, number (you can set up to 10 numbers), and finally click "SAVE" to save.

Edit a contact: Click "Function" in the app, select "Settings" → Phone book → drag to select the number you want to edit → Save after editing.

Delete a contact: Click "Function" in the app, select "Settings" → Phone book → drag the number you want to delete → Click "Delete" (the deleted information will be synchronized in the watches and the app).

### (2) Calling:

Use the directory to call: Click the "Contacts" icon on the watch to display the list of contacts, scroll up and down to select a contact to call.

One-button SOS call: In case of emergency, press the RED button for 3 seconds to trigger the emergency SOS call. At that time, the watch will call the 3 preset emergency numbers circularly.

Dial a number: Click the "Keyboard" icon on the watch, enter the phone numbers manually, and dial the number.

## Chat features:

### (1) Voice message:

From the app to the watch: Click "Chat" on the main page of the app, you can send a voice message to the watch.

From the watch to the app: Click the "Chat" icon on the watch - press and hold the talk button to speak - release your finger to finish recording.

### (2) Video chat:

1. The app initiates a video chat: Click "Function" "Video chat" in the app.

2. The watch initiates a video chat: Click the "VideoCall" icon on the E flea watch, select a contact, and click.

## Camera:

(1) GPS watch to take pictures: Click "camera" on the E flea watch to access the camera interface, click the icon in the middle of the camera to take pictures. Click the photo icon in the lower right corner to access the gallery page, you can view or delete photos.

(2) E flea watch to record videos: Click "camera" on the E flea watch to access the camera interface, click the camera icon to record videos. Click the photo icon in the lower right corner to access the gallery page, you can view or delete videos.

## Health pedometer:

Pedometer settings: Function of the app, Step settings, click the "+" icon to add the pedometer time period, and click Save.